

Software Error Notification Form

Form 3.5.1 | Revision: 0 | Effective: 6/15/02 | Pg. 1 of 1

	C RADTRAD 3.03_ evisions 0 & 1		Page <u>1</u> of <u>1</u>	
Description of Error: When a user runs the GUI version throughthe acceptance test case sequence, some results are different from those calculated by the batch version. For example test case 1a after test case 19 will have an incorrect value for the worst 2 hour EAB dose. The edited value at 2 hours is correct.				
Recommendations to Program Users: The error does not impact code results. If the user feels that this may be a problem they should run the case separately to determine the correct answer, i.e. initiate the RADTRAD GUI, bring in the input, and calculate.				
Software Program Manager:	Jack Dallman Printed/typed Name	Signature	Date	
SW Point of Contact:	Terry Heames Printed/typed Name	Signature	Date	
Corrective Action: .Primary output routine was modified to include more initialization. The modifications have been sent to Bill Arceiri (ISL) and will be included in the NRC release version.				
	Verified Complete:QA Manager			
Software Program Manager:	Jack Dallman Printed/typed Name	Signature	Date	
SW Point of Contact:	Terry Heames Printed/typed Name	Signature	Date	